


# TIP-RESISTANT FURNITURE SAFETY BRACKET


## HARDWARE BAG CONTENT



- Designed to help prevent furniture tipping over.  
 - Also helps prevent furniture tipping over during minor tremors.


## INSTALLATION:

- Fix the metallic bracket (4) on the back of your furniture, below the top, by inserting 3 wood screws (2) into the pre-drilled holes.
- Temporarily move the furniture into its final position. Mark the position of the metallic bracket (4) on the wall.
- Move the furniture away from the wall.
- Drill a pilot hole into the center of the wall mark with a diameter according to the diagram shown below.
- Fix one of the items 1, 3 or 6 (depicted above) into the wall, depending of the wall type, to ensure a strong anchor for your furniture.
- Move the furniture back into its final position, taking care to line up the metallic bracket (4) with the corresponding bracket fixed into the wall.
- Thread the plastic strap (5) through the metallic bracket (4) and through the the wall anchor then tighten until snug. Do not over tighten.




concrete wall  
or brick wall

Ø 1/2" pilot hole



wall stud sheetrock wall

Ø 1/8" pilot hole



sheetrock wall

Ø 5/16" pilot hole

## IMPORTANT:

- Check to make sure that the wall bracket is firmly screwed into the wall, the furniture bracket is firmly attached to the cabinet and the strap is snug;
- Cable ties can become brittle and snap after some time, so check them frequently.

## CAUTION:

- This product is not to be a substitute for a proper supervision. Always monitor your child's activity when in the nursery.
- Manufacturer assumes no liability for improper installation or excessive loads placed on the screws, brackets or straps.
- Ensure that children do not step or lean against open drawers or shelves.
- Do not open more than one drawer at a time.
- Place any items that may be of interest to a child within easy reach so that they are not enticed to climb for it.

Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Be sure to use furniture wall straps to help reduce the risk of tip-over. Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.
- Do not overload drawers.
- Do not allow children to climb or hang on drawers, doors, shelves or any piece of furniture.
- Do not allow children to play on furniture.

This hardware is only a deterrent. Adult supervision is the only proper deterrent to prevent improper use of the units.

*Regular cleaning with mild soap on a soft cloth, followed by a clean damp cloth, then a dry cloth, will preserve the original luster and beauty of the fine finish of your Romina Furniture product.*



*Thank you for being one of our distinguished clients.*

**Romina**<sup>®</sup>  
furniture *Team*

*Visit*  
**[www.rominakidsfurniture.com](http://www.rominakidsfurniture.com)**  
*for updates, special offers and more new designs.*

